Technical Service Bulletin

Cobra Motorcycle Mfg.

240 Uran street
Hillsdale, MI 49242

(517) 437-9100 phone
(517) 437-9101 fax

TSB1212 Three Shoe Clutch Assembly

April 19, 2012

From this day forward Cobra will be assembling the clutch bolts with either of the following two processes;

- Clean the bolt threads thoroughly
- Apply Loctite 2760 to the threads
- Apply Loctite primer 7471 to the arbor
- Torque to 16 Nm

Or

- Clean the bolt threads thoroughly
- Apply Loctite 263 to the threads
- Torque to 16 Nm

CAUTION:
To aid disassembly, clutch bolts assembled in this manner will likely require the application of heat to the arbor. Attempting removal without the application of heat may result in broken bolts.